

User manual for usb keyboard cover.

- All holders are made of metal and flexible.
 For the best result: to clamp your tablet or e-reader in the cover you have to bend these towards the unit at about the thickness of your device before you slide it into the cover.
 If the results are not yet sufficiently repeat the previous step because you do not have to worry that the holders will break.
- If a holder covers an input or button that you need you can bend the holder out or rotate your device 180 degrees and put it back in the cover Your screen tilts when not turned off in the settings Alternatively you also can move your device a little bit in the holders.
- To put the cover down, expand the rear support.

Tips for problems with the usb keyboardcase.

- In case of problems please connect the keyboard case on a regular computer or laptop and then test whether there is the same problem. Also check if the "numlock' isn't on.
- Does it work properly on a normal computer or laptop then the problem is with your tablet or the settings and/or the latest update has not been implemented. Sometimes the insertion of an USB- hub will help. For this you should contact your supplier, they can provide support for this. Optionally a forum on the internet is also a good place to get questions answered.
- It will also help if you download a file which can be found on our website under the heading "news" .